

**SMR04-
SMR100**

- 1) The nominal electrical power can be calculated using the following formula: $P = U \times I \times \cos \phi$
- 2) Current at operating torque
- 3) Current at MARx. torque. We recommend to select switchgears according to these values.
- 4) Assignment of switchgears when using kikit controls of types SC01. C1≤3KW: 3KW<C2≤6KW: C3>6KW: T1≤1.5KW: 1.5KW<T2≤3KW



T01.02/en